OXYGEN FILLER VALVE - MAINTENANCE PRACTICES


1. General


A. The oxygen filler valve is located behind a cover assembly located on the right side of the airplane at FS 309.90 on Model 208, and FS 357.90 on the 208B. The cover assembly is attached by 4-1/4 turn flush-head studs.

2. Oxygen Filler Valve Removal/Installation

WARNING: Disconnect the high-pressure line from the regulator before attempting any service procedure on the high-pressure side of the system (indicating or filler valve).

- A. Remove Oxygen Filler Valve (Refer to Figure 201).
 - (1) Remove aft baggage partition to gain access to filler valve assembly.
 - (2) Loosen line assembly (11) from filler valve body (10).
 - (3) Unscrew filler valve from body filler valve end (5).
 - (4) Remove sleeve assembly (8) from filler valve end (5).
 - (5) Remove O-rings (12) and (13) from sleeve assembly (8).
 NOTE: The O-rings are the only field-repairable/replaceable parts of the filler valve assembly.
 - (6) If filler valve end (5) is damaged, remove by loosening screws (4) from outside of airplane through access port.
- B. Install Oxygen Filler Valve (Refer to Figure 201).
 - (1) Install O-rings (12) and (13) on sleeve assembly (8).
 - (2) Ensure that valve core (9) is properly positioned in filler body assembly and bronze filter (7) is positioned in sleeve assembly (8).
 - (3) Screw filler valve assembly into filler valve end (5).
 - (4) Attach line assembly (11) to filler valve body (10).
 - (5) Test for leaks.
 - (6) Reinstall aft baggage partition.





2614X1219

Model 208/208B Maintenance Manual (Rev 33) 35-11-00-2 (Original Issue)

