

**LEVELING AND WEIGHING - GENERAL**

**1. Scope**

- A. This chapter provides information necessary to properly level the airplane for any maintenance, overhaul or major repairs which might become necessary.
- B. For information on airplane weighing procedures, refer to the Pilot's Operating Handbook.

**2. Tools, Equipment and Material**

NAME	NUMBER	MANUFACTURER	USE
Spirit Level		Commercially available	Bubble level used to level airplane.

**3. Definition**

- A. Leveling.
  - (1) The section on leveling provides maintenance practices and instructions for longitudinal and lateral leveling of the airplane. This leveling is accomplished using a spirit level of at least 18 inches in length.