

HEATING AND DEFROSTING AIR DISTRIBUTION - TROUBLESHOOTING

1. General

- A. Troubleshooting of heating/defrost air distribution system should be performed anytime output flow falls below normal parameters.
- B. A troubleshooting chart has been prepared to aid maintenance technician in system troubleshooting. Refer to Figure 101.

Figure 101 : Sheet 1 : Heater and Defroster Troubleshooting Chart

A10001

