PORTABLE FIRE EXTINGUISHING - DESCRIPTION AND OPERATION

1. General

A. Portable, hand operated fire extinguishers are mounted in easily accessible locations for use in the event of a fire. (Refer to Figure 1).

2. Description and Operation

A. One portable fire extinguisher is mounted in the flight compartment on the pilot so door, or mounted between the pilot and copilot seats on the cargo barrier. An approved extinguishing agent can be used on solid combustible, electrical or liquid fires. Servicing of the extinguisher can be handled by most fire equipment dealers. The fire extinguishers are mounted within a quick release, clamp type bracket assembly. An optional additional portable fire extinguisher can be installed at FS 257.0 between RBL 14.0 and RBL 23.5, installed on the seat tracks of the most aft right seat of the airplane forward of the main cabin door entry door. The fire extinguisher and quick release bracket is identical to the one mounted in the flight crew area.




Figure 1 : Sheet 1 : Portable Fire Extinguisher Installation

A85811 Fire Extinguisher Assembly Seat Rails **Bracket Assembly** Quick Release Clamps Handle Safety Pin Discharge Lever DETAILD D2614T1423

Figure 1 : Sheet 2 : Portable Fire Extinguisher Installation




Figure 1 : Sheet 3 : Portable Fire Extinguisher Installation