

PNEUMATIC SURFACE DEICE - INSPECTION/CHECK**1. General**

- A. This section has the inspections and checks necessary to keep the pneumatic surface deice system in a serviceable condition.

TASK 30-10-00-720**2. Bleed Air Pressure Regulator Functional Check**

- A. General
 - (1) This task gives the procedures to do a bleed air pressure regulator functional check.
- B. Special Tools
 - (1) Filtered Shop Air
 - (2) Flexible Hose
 - (3) Pressure Gage
- C. Access
 - (1) Open the right engine cowl door.
- D. Do the Bleed Air Pressure Regulator Functional Check.
 - (1) For the procedures necessary to do the bleed air pressure regulator functional check, refer to Chapter 36, Pneumatic Distribution - Maintenance Practices.
- E. Restore Access
 - (1) Close the right engine cowl door.

END OF TASK