

BENDIX/KING KT-73 MODE-S TRANSPONDER - ADJUSTMENT/TEST**1. General**

- A. This section gives information necessary to do a self test of the Bendix/King KT-73 Mode-S transponder.
- B. The KT-73 Mode-S transponder is in the center radio panel.

2. KT-73 Self Test

- A. Do a Self-Test of the KT-73 Transponder.
 - (1) Make sure that there is power to the KT-73 transponder.
 - (2) Turn the selection knob to the TST position.
 - (3) Make sure that all display segments come on for a minimum of four (4) seconds after the TST position is selected.
 - (4) Make sure that a TEST OK message comes on after four (4) seconds.
 - (5) If any other message comes on after four (4) seconds, refer to the Model 208 Illustrated Parts Catalog - List of Vendor Publications.
 - (6) Set the KT-73 transponder to the SBY position.