

## LEVELING AND WEIGHING - GENERAL

### 1. Scope

- A. This chapter provides information necessary to properly level the airplane for any maintenance, overhaul or major repairs which might become necessary.
- B. For information on airplane weighing procedures, refer to the Pilot's Operating Handbook.

### 2. Tools, Equipment and Material

NAME	NUMBER	MANUFACTURER	USE
Spirit Level		Commercially available	Bubble level used to level airplane.

### 3. Definition

- A. Leveling.
  - (1) The section on leveling provides maintenance practices and instructions for longitudinal and lateral leveling of the airplane. This leveling is accomplished using a spirit level of at least 18 inches in length.