

## ATTITUDE AND DIRECTION - DESCRIPTION AND OPERATION

### 1. Description

- A. This section contains information pertaining to such items as magnetic compass, turn and bank indicator, and stall warning system. For information pertaining to standard gyros, refer to Chapter 37 of this manual, Vacuum Indicating - Maintenance Practices. For information pertaining to optional gyros, refer to Model 208 Avionics Installations Manual.