

## BENDIX/KING KT-73 MODE-S TRANSPONDER - ADJUSTMENT/TEST

### 1. General

- A. This section gives information necessary to do a self test of the Bendix/King KT-73 Mode-S transponder.
- B. The KT-73 Mode-S transponder is in the center radio panel.

### 2. KT-73 Self Test

- A. Do a Self-Test of the KT-73 Transponder.
  - (1) Make sure that there is power to the KT-73 transponder.
  - (2) Turn the selection knob to the TST position.
  - (3) Make sure that all display segments come on for a minimum of four (4) seconds after the TST position is selected.
  - (4) Make sure that a TEST OK message comes on after four (4) seconds.
  - (5) If any other message comes on after four (4) seconds, refer to the Model 208 Illustrated Parts Catalog - List of Vendor Publications.
  - (6) Set the KT-73 transponder to the SBY position.