

## VACUUM - GENERAL

### 1. Scope

- A. This chapter describes those units and components used to provide suction (vacuum) necessary to operate the horizon and directional indicator gyros.

### 2. Definition

- A. This chapter is divided into sections to aid maintenance personnel in locating information. Consulting the Table of Contents will further assist in locating a particular subject. A brief definition of the sections incorporated in this chapter is as follows:
  - (1) The section on distribution describes those components used in the distribution of vacuum air.
  - (2) The section on indicating describes those components used to indicate relative vacuum pressure in the system.